## Ed Brown Products, Inc.

edbrown.com/instructions • edbrown.com/contact



## **Glock Sight Tool**

The hole in the bottom of the 6" slides may need to be opened a small amount for the tool to fit through. We recommend you use a carbide drill or high speed dremel as the slide material is extremely tough. It is impossible to reduce the diameter of our tool enough to fit in the existing hole.